

Ground Master Monitor

Installation, Operation and Maintenance



Made in the
United States of America

The Ground Master Monitor and its accessories are available as the following item numbers:

Item	Description
770044	Ground Master Monitor
CTC065-C	Ground Master Extension Cable Unit
CTE701	Workstation Monitor Checker
770064	Power Adapter, 7.5 VDC
770121	SMP Web App



Static Management Program

The SCS Ground Master Monitor is compatible with SCS Static Management Program (SMP). SMP continuously monitors ESD control programs throughout all stages of manufacturing. SMP captures data from SCS continuous monitors and ionizers to provide a real-time picture of critical manufacturing processes. All activity is captured and stored in a centralized database for on-going quality control purposes. Reports generated by SMP reveal areas of concern, enable proactive prevention of ESD events, and validate the efficiency of a ESD control program. SMP captures tool impedance and tool EMI voltage measurements from the Ground Master Monitor.

SMP is sold separately. [Click here](#) to learn more.

Packaging

- 1 Ground Master Monitor
- 1 Monitor Ground Cord (Green and Yellow)
- 4 Replacement Fuses (250 VAC, 125 mA)
- 1 Ring Terminal
- 1 Screw, Pan-Head, 6-32 x 1/4"
- 1 Star Washer
- 1 Power Adapter, 7.5 VDC, with interchangeable plugs (North America, UK/Asia, Europe, China)



Figure 1. SCS 770044 Ground Master Monitor

Description

The SCS Ground Master Monitor is an equipment ground continuous monitor for metal tools. It continuously monitors the path-to-ground impedance and electromagnetic integrity of eight metal ground connections of process tools in work areas. This includes semiconductor, disk drive, flat panel, and electronic equipment manufacturing environments. The monitor provides both visual and audible alarms and includes fuse protection for each channel.

The Ground Master Monitor continuously monitors eight metal tools for electromagnetic interference (EMI). EMI can cause equipment lockups and malfunction. The Ground Master Monitor will alarm if EMI is detected. Each Ground Master Monitor is calibrated with accepted procedures and standards traceable to the National Institute of Standards and Technology (NIST).

The Ground Master Monitor meets the Continuous Monitor requirements of ANSI/ESD S20.20 in accordance with ESD TR53. It meets the recommendations of ESD Handbook ESD TR20.20 which includes "if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required".

Features and Components




Figure 2. Ground Master Monitor features and components

A. Diagnostics Port: For manufacturer use only.

B. Test Limit Rotary Switch: Sets the test limit of the tool monitor circuits from 1 to 20 ohms.

Setting	Test Limit
1	1 ohm
2	2 ohms
3	3 ohms
4	4 ohms
5	5 ohms
6	6 ohms
7	7 ohms
8	8 ohms
9	9 ohms
A	10 ohms*
B	12 ohms
C	14 ohms
D	16 ohms
E	18 ohms
F	20 ohms

*default setting

C. Power LED: Illuminates yellow when the monitor is powered.

D. Tool LEDs: Illuminates green when its respective tool is within the impedance and electromagnetic interference (EMI) voltage test limits. Blinks red when its respective tool exceeds the EMI voltage limit. Illuminates solid red and audible alarm sounds when its respective tool exceeds the impedance test limit.

E. Tool Monitor Switches: Slide the switch up to enable its respective tool monitor circuit. Slide the switch down to disable its respective tool monitor circuit.

F. Audible Alarm Switch: Enables and disables the monitor's audible alarm.

G. Communication LED: Blinks when the monitor is powered and communicating to SMP Server.

H. Protective Fuses: Protects the spread of harmful voltage to other tools via the Ground Master Monitor should one of the tools become exposed to excessive voltage. The appropriate fuse will disconnect the faulty tool from the Ground Master Monitor and from the other connected tools.

I. Optical Relay Terminals: Integrates with electronic tools, lights, buzzers, etc. The relay opens when the monitor enters a ground alarm condition, and it remains closed otherwise.

Relay Parameter	Rating
Peak Blocking Voltage	400 V _P
Load Current	140 mA _{rms} / mA _{DC}
On-Resistance (max)	22 ohms

J. Power Input Terminals: Accepts 7-24 VDC input from an external source for powering the Ground Master Monitor.

K. Monitored Tool Terminals: Monitors metal tools for proper conductive impedance and electromagnetic interference (EMI) voltage. Use 28-16 AWG wire to connect the metal tools to these terminals.

L. Ethernet Jack: Provides network communication between the Ground Master Monitor and [Static Management Program \(SMP\)](#).

M. Power Jack: Connect the included power adapter here.

N. Ground Terminal: Common ground point for the monitor.

Installation

Hardware Setup

1. Remove the Ground Master Monitor from the carton, and inspect for damage.
2. Determine the mounting location of the Ground Master Monitor, and use its mounting tabs to secure it. Its display should be visible to the operator(s).
3. Secure one end of the included ground cord to the ground terminal located on the bottom-side of the Ground Master Monitor. Attach the other end of the cord to a ground point. The face plate screw of a grounded AC wall outlet may provide a convenient connection point.
4. Insert stripped terminations of 28-16 AWG wires (not included) into the monitored tool terminals located on the bottom-side of the Ground Master Monitor. Ensure that the tool monitor switches are enabled if using these monitored tool terminals.
5. Route the tool monitor wires from the bottom-side of the Ground Master Monitor to their respective grounded metal tools, and secure them. Keep the wires as short as possible. Do not loop or coil them as it may affect the measured impedance.

6. Connect an Ethernet cable to the Ethernet jack located on the bottom-side of the Ground Master Monitor. Verify that the cable is properly connected to a network.
7. Connect the power adapter to the power jack located on the bottom-side of the Ground Master Monitor. Route the wire from the supply to a nearby AC outlet and plug it into the outlet. Make sure the voltage and frequency match those listed on the power supply. The Ground Master Monitor is now powered.




Figure 3. Wiring the Ground Master Monitor to two metal tools




Figure 4. Mounting hole locations (all dimensions are in inches)

SMP Network Setup

The following procedure outlines how to connect the Ground Master Monitor to SMP via a local area network (LAN). SMP must be installed on a PC prior to using this procedure. The diagram shown below illustrates a common SMP system setup that utilizes the server software, client software, SW Aware Monitor, WS Aware Monitor, EM Aware Monitor, Ground Master Monitor, and Ion Pro™ Benchtop Ionizer.






Figure 5. SMP system setup


1. Verify that the Ethernet cable is securely connected to the network and Ground Master Monitor. The LEDs on the Ethernet port will illuminate when a connection to the network is established.
2. Log into the SMP Web App with either the default credentials (see user guide [TB-9116](#)) or ones provided by the SMP Admin.



3. The dashboard view will provide activity for all SMP devices.



- Go to the Live > Status page to view the status of the Ground Master Monitor.



- Select the device name to access the live results for all Ground Master Monitor channels. The shortcuts at the top of the window are for generating history reports, toggling between different views of the data, zooming in/out, and showing/hiding the Alarms panel.

Workstation 1		Workstation 2	
Metal Ground EMI Voltage 1	0.01 mV	Metal Ground EMI Voltage 2	0.01 mV
Metal Ground Impedance 1	1.82 Ω	Metal Ground Impedance 2	121.05 Ω
Workstation 3		Workstation 4	
Metal Ground EMI Voltage 3	0.00 mV	Metal Ground EMI Voltage 4	0.01 mV
Metal Ground Impedance 3	1.70 Ω	Metal Ground Impedance 4	1.84 Ω
Workstation 5		Workstation 6	
Metal Ground EMI Voltage 5	0.00 mV	Metal Ground EMI Voltage 6	0.01 mV
Metal Ground Impedance 5	120.79 Ω	Metal Ground Impedance 6	0.48 Ω
Workstation 7		Workstation 8	
Metal Ground EMI Voltage 7	0.01 mV	Metal Ground EMI Voltage 8	0.01 mV
Metal Ground Impedance 7	1.01 Ω	Metal Ground Impedance 8	120.82 Ω

6. Go to the Administration > Devices page and select the Edit icon to access the Ground Master Monitor's settings. In this screen, the device may be assigned a name, attached to a line, and have its settings adjusted. The exclamation (!) icon displays the available settings for the Ground Master Monitor.

The screenshot shows a web browser window with the URL `192.168.9.125:20200/devices/3`. The page is titled "Device" and features a sidebar with navigation options: Live, Reports, Administration (selected), Devices, Lines, Locations, Solutions, Users, Tools, and Language. The main content area displays the configuration for a "Ground Master Monitor" with serial number "E91004233201" and status "Active". The configuration is divided into two sections: "Alarms" and "Warnings". The "Alarms" section includes a "Metal Ground Impedance Limit (Ω)" set to "10" and an "EMI Voltage Limit (mV)" set to "198.4". The "Warnings" section includes a "Metal Ground Impedance Warning (Ω)" and an "EMI Voltage Warning (mV)". A green "+" button is visible next to the "Line" field.

7. Note: The EMI Voltage Limit (mV) is the only available limit that can be adjusted. The Metal Ground Impedance Limit (Ω) must be adjusted at the monitor.

Operation

Use the table below to interpret the behavior of the Ground Master Monitor's tool LED's and audible buzzer (if enabled).

Green LED	Red LED	Buzzer	Status
ON	OFF	OFF	No failures
OFF	ON	ON	Impedance failure
ON	BLINK	OFF	EMI voltage failure
OFF	OFF	OFF	Monitor channel disabled

Maintenance

Cleaning

Disconnect the power adapter from the device. Clean the Ground Master Monitor using a dry brush or vacuum cleaner. Clean its contacts using a contact cleaner or brush, and tighten all connections. Do not reconnect the power adapter until cleaning is finished.

Replacing the Fuses

The monitored equipment may become prone to excessive voltage and significant damage should it lose its connection to ground or be bonded to an improperly wired ground point. In order to prevent the spread of this excessive voltage to other equipment via the Ground Master Monitor, fuses are implemented for each individual ground connection. In the case of excessive voltage on the equipment, the appropriate fuse will disconnect the equipment from the Ground Master Monitor and from the other connected equipment. Ground failure on that particular ground will be immediately indicated.

Before replacing the fuse, always investigate the reason for the fuse blowing, and correct the problem. The fuse should never blow under normal circumstances.

NOTE: Never use wire jumpers in place of fuses. Use only factory-authorized fuses. Disconnect power before replacing any fuses. The fuses are manufactured by Littelfuse®, and its part number is 37301250410.

Calibration

Frequency of recalibration should be based on the critical nature of those ESD sensitive items handled and the risk of failure for the ESD protective equipment and materials. In general, SCS recommends that calibration be performed annually.

Use the SCS CTE701 Workstation Monitor Checker to perform periodic verification (once every 6-12 months) of the Ground Master Monitor. The Workstation Monitor Checker can be used to check the test limits of the Ground Master Monitor without removing it from the factory floor.

See [TB-9031](#) for more information.



Figure 6. SCS CTE701 Workstation Monitor Checker

Specifications

Input Voltage and Frequency (External Adapter)	Power Input: 100-240 VAC, 50/60 Hz Power Output: 7.5 VDC @ 1.5 A Cable Length: 6 ft. (1.8 m) Output Connector: 5.5 mm O.D. x 2.1 mm I.D. x 9.5 mm L
Current Consumption	50 mA
Operating Temperature	50 to 95° F (10 to 35° C)
Dimensions	3.54" x 5.52" x 1.18" (90 mm x 140 mm x 30 mm)
Weight	0.4 lbs. (0.18 kg)
Tool Monitor Circuits	8
Default Test Limit	10 ohms impedance
EMI Voltage Limit	223 mV average amplitude (@ 1.5 MHz)
Test Voltage	80 mV square pulse @ open circuit (80 Hz)
Test Current	<5 mA @ short circuit
Input Connectivity	28-16 AWG wire terminal blocks for metal tools
Output Connectivity	28-16 AWG wire terminal blocks for relay outputs
Certifications	CE
Country of Origin	United States of America

Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the SCS Warranty -
StaticControl.com/Limited-Warranty.aspx