

Hand Switch EL Basic for Box Lifter - Bosch Rexroth 3842546998

Item no. BRR-3842546998

Manufacturer Bosch Rexroth

The EL Basic hand switch is the manual control element for Bosch Rexroth box lifting devices. It operates the lifting and lowering movement directly at the workstation. A matching holder is available as recommended accessory.

TECHNICAL DATA

HS-Code **85371098**

Weight **0.48 kg**



DESCRIPTION

The EL Basic hand switch is the manual control element for Bosch Rexroth box lifting devices. It lets the operator control the lifting and lowering movement directly at the workstation.

- Manual operation in the Basic version
- Direct control at the box lifting device
- Matching holder available as recommended accessory

TECHNICAL DATA

Version	Basic
Recommended accessories	Holder for hand switch
Weight	0.48 kg